

# Fall Harvest Days

## ANTIQUUE TRACTOR PULL RULES 2022

**A Tractor may enter more than one class.**

Any fuel mixtures or pressure tanks are not allowed such as fuel pumps in the Light and Heavy Classes. LP is allowed in all classes. No alcohol, nitro, or nitrous oxide of any type. Club has the right to check fuel at any time.

**Tractors must operate with a hand throttle as comes from the factory.**

No weight frame may extend more than 24" beyond the front of the tractor frame.

**Tractor must be equipped with a hoop hitch or twisted clevis.**

Must run an original or stock carburetor. Manifolds may be updated with a replacement. The governor must be stock both internal and external.

**Diesel tractors must run original or stock pumps and fuel systems in all classes.**

Air Breathers are not necessary, but if used must be in a relatively stock location. Any variance must be approved by the Club Techs.

**Tractors must run OEM type ignition system as it came from the factory.**

A Ignition Switch is necessary that the driver can shut off from the seat.

Magneto equipped tractors are excluded.

**Starters are allowed on early tractors.**

Drawbar height may not exceed 20" in height and will be checked.

Pulling off of three-point arms is not allowed.

**Rubber tires only.**

Driver must remain seated while pulling.

**Disqualification will apply if anything falls off of the tractor while pulling.**

Front wheels may not raise past 16" off of the ground while pulling. Wheelie bars are encouraged.

**The Flagman's and Club Official's Decisions are final.** 3/2022 REV1